Installation & Fitting Instructions

MILENCO

2042 Door Lock

Fitting



Use Gasket to mark drill position



Drill 4 holes 7mm diameter



Mount inside backing plate and insert 4 screws



Affix gasket



Mount and tighten 4 x M6 screws



Fit trim cover plate



Inside view of mounting cover Width 105mm x Height 90mm